

How to change the Time on STS, and XTS Flash Voicemail Systems

Press **VMAIL** or **450** on your phone or call your main number.

Press * (star) and then # (pound).

Enter Mailbox #00

Enter password 9#56

Press 4

Follow prompts as follows:

Press 1 to review time and date.

Press 2 to change time and date.

Enter time in 24 hour format HH : MM.

Enter date in Month: Day: 4 digit Year format.

Press * (Star) to exit.

Press On/Off Button to exit voicemail programming.

Note

If your system has 2 digit extensions the mailbox you enter is #0.

If your system has 4 digit extensions the mailbox you enter is #000.

If you have any questions please feel free to call us @ 303-688-6191