

Changing The Name In The Display of Your Phone for SBX-IP 320

You can designate a "name" for your station. This name will appear on your display, as well as the display of any other station in your system that you call or that calls you.

1. Use ▲ on the Nav Button to access the Programming Menu.
2. Press the OK soft button to select the BASIC PROGRAM option.

1. **BASIC PROGRAM**
2. ADVANCED PROGRAM
OK



3. Make sure the STATION NAME PROGRAM option is selected.
4. Press the OK soft button to select the STATION NAME PROGRAM option.

1. **STATION NAME PROGRAM**
2. RING PROGRAM
BACK OK



5. Enter the name you want to have appear on the display
(See page 2 of pdf)

ENTER NAME ()
BACK OK



6. Press HOLD/SAVE to save the entry.
- The name will now appear on your display.

JAMES PAUL (T)
DEC 03 08 02:34 pm
PICKUP CONF REDIAL-->

If you have any questions please feel free to call us @ 303-688-6191

Page 1/2

Entering Characters for Display Entries

In addition to using the dialpad to enter numbers on the display, You may need to use it to also enter text when using various features that allow you to enter text on the display (such as Station Name Programming, Pre-selected Messages, Phonebook entries, and Speed Dialing entries).

Use the table below to locate the letter, number, and symbol codes that allow you to enter text on your display.

Example: To enter the name MARY, you would use the dialpad to enter the number series: 61 (for M), 21 (for A), 73 (for R), and 93 (for Y).

21 = A	32 = E	43 = I	61 = M
22 = B	33 = F	51 = J	62 = N
23 = C	41 = G	52 = K	63 = O
31 = D	42 = H	53 = L	71 = P
72 = Q	82 = U	93 = Y	13 = .
73 = R	83 = V	94 = Z	*1 = SPACE
74 = S	91 = W		*2 = :
81 = T	92 = X		*3 = ,
00 = 0	40 = 4	80 = 8	
10 = 1	50 = 5	90 = 9	
20 = 2	60 = 6		
30 = 3	70 = 7		