

To change your night message for the Holiday Break for the LG/ Ericsson iPECS Telephone System

1. Record your greeting
2. Press the trans/prog key, dial 06, dial 002, then dial 1. Press the # key to record. To listen to your greeting, perform the same but don't hit the # button.
3. At the attendant phone, hit the DND button, dial 2 and hold.
4. You now have the greeting for your holiday vacation.
5. When you return from break, Press the DND button and press 4, then Hold this will put your system back into the auto ring mode.

If you have any questions please call System Communications at 303-688-6191 x103